


# Service Manual

Battery charger

## EY0230

### SPECIFICATIONS

Input : 120V AC 50-60Hz 1.8A  
 Output : 15.6V DC 3.75A  
 Weight : 0.78kg (1.72lbs)




### ⚠ WARNING

This service literature is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

# Panasonic

©1999 Matsushita Electric Works, Ltd.  
 All rights reserved. Unauthorized copying  
 and distribution is a violation of law.

## EXPLODED VIEW




## REPLACEMENT PARTS LIST

NOTE : \*A . . . available as an optional accessory

\*B . . . only available as set

\*C . . . available individually

Ref.No.	Part No.	Part Name & Descriptions	Per unit	Remarks
1	EY0230K3098	HOUSING A	1	
2	EY0230K3028	HOUSING B	1	
3	EY0230L2128	MODULE	1	
4	EY0230L5258	FUSE	1	125V 3A
5	EY0230K2058	POWER CORD	1	
6	EY0217K6237	TAPPING SCREW FOR CHARGER	4	*C
▲ -	EY0230K8008	INDIVIDUAL BOX	1	
▲ -	EY0230K8108	OPERATING INSTRUCTIONS	1	

**SCHEMATIC DIAGRAM**

# TROUBLESHOOTING GUIDE

